



## **Manifold Pressure Test Kit**

- Teflon Tape or plumber's dope must be used on all metal to metal thread
- Replace Teflon tape or plumber's dope each time the pressure test kit is used to ensure airtight seal
- Works with most Classic, Stainless Steel, and Deluxe Rifeng Manifolds.
- For Air Pressure Testing only
- Use pressure test kit before, during and after concrete pour
- Gas Teflon Tape or plumber's dope must be used on all metal to metal thread
- Do not use the Pressure Test Kit while purging air out from system or when filling the system with water.
- Use the 3/4" Nipple and Bushing to 1" when necessary
- Pressurize to 30-40 psi (recommended) and hold pressure for at least 1 hour preferably overnight.