


RB-5 Clip Gun Operating Instructions



1. Shoot three times.

To fasten a pipe or tube with the RB-5 Clip Gun, **press and hold** the Clip Gun **firmly** against the wooden surface. Then, **fire the gun three times** per clip.

Firing the gun three times will drive the nails out of the clip housing and into the wooden surface. It takes less than two seconds to seat each clip by firing the Clip Gun three times. A fully seated, properly installed RB-5 Clip will provide an installation that is strong and professional.

2. Rotate off.

On the third firing, the handle should be held down and the gun rotated away from the installed clip.

The forked driver blade that hammers the nails into the wood will have penetrated the clip housing to a depth of 5/8". Rotating the gun off the clip will prevent the driver blade from binding within the clip housing. Shaking the gun to pull it off of the clip will tend to loosen the nails.

Safety

- **Do not point the Clip Gun at anybody.**
Although the RB-5 Clip Gun is designed to not fire clips out of the magazine, the nails will protrude quickly upon firing and could cause injury.
- **Do not overreach when operating gun from a ladder.**
Keep proper footing at all times.
- **Do not fire the Clip Gun unless it is engaged in installing pipe or tubing onto a wooden surface.**
- **Wear safety glasses when using the Clip Gun.**

REMINDER

It takes less than two seconds
to fire the Clip Gun three times!

Comments? Suggestions? If you have any questions about the operation of the RB-5 Clip Gun or its applications, please call us during business hours, Monday - Friday 8:00 am to 5:00 pm (Mountain Time) and we'll be happy to help. Our toll free number is 1-800-338-2448.

 **Peter Mangone, Inc.**

PLUMBING PRODUCTS DIVISION

Lakewood, Colorado USA

800-338-2448 • mail@petermangone.com • www.petermangone.com